

EasiSolv 140 Solvent Cleaner

Product Description:

EasiSolv[™] 140 Solvent Cleaner is a quick drying cleaner formulated to effectively dissolve and remove printing inks from screen printing mesh, squeegees, flood bars, presses, pad printing tools, rotary screens and more. This product with its unique combination of cleaners, has a flash point over 140° F, making it much safer and simpler to dispose of compared to lower flash, volatile solvents. This product is ideal for on press color changes, screen opening, or save screens.

Physical & Chemical Data:

Appearance & Odor: Clear liquid with aromatic odor.

Specific Gravity: 0.93 @ 20 °C / 68 °F

Vapor Pressure: .44 mm Hg @ 20 °C / 68 °F

Vapor Density: Heavier than air Boiling Point: > 192 °C / 378 °F

pH: Neutral

VOC: 930 grams/liter **Flash Point:** 142 °F / 61 °C

Special features:

- EasiSolv 140 effectively dissolves most inks, including: conventional/solvent, UV, plastisol and water base.
- EasiSolv 140 is non-flammable (flash point of 142 °F) which makes it safer for handling, storage and rag disposal than conventional solvent cleaners.
- EasiSolv 140 dries fast... providing a safe, odor-free alternative to hazardous, flammable solvents.
- EasiSolv 140 is not SARA (Superfund Amendments Reauthorization Act) reportable which requires less solvent monitoring and paperwork.
- EasiSolv 140 may be applied manually or recirculated through the EasiFlo™ System, or in an enclosed, automatic screen washing system, providing superior product life and economy.

Application:

- Scrape all excess ink from screen.
- Apply EasiSolv 140 by squirt bottle, pneumatic sprayer or by rag to the (well) ink side of the screen.
- Thoroughly agitate ink with a rag or scrubber, then wipe up all dissolved ink.
- Reapply if necessary and follow with a dry rag, wipe on both sides of the screen.
- The screen will be ready for printing or tape application within 20 seconds.